



## Installation procedures

Before you begin, please check the following with the manager or head mechanic. Document these inspections, and have the manager sign this pre-inspection.

1. Check the operation of all foul lights.
2. Check to see if all pinsetters cycle at the ball rack.
3. Check to see if the managers control switches at the front desk are operational. For AMF centers, verify the practice mode (shadow bowling) is operational.
4. Check to see if both 1<sup>st</sup> and 2<sup>nd</sup> ball lights on the masking unit are operational.

### **Items below are the requirements of Steltronic North America, Inc**

1. All zip ties must be cut.
2. All wires must be placed and mounted in a way that they cannot be damaged by a bowling ball.
3. All cables must be secured in a way that they cannot be pulled off or damaged by mechanic. The I-Retro or API cables must be secured. The camera cables must be secured so a bowling ball cannot damage it.
4. All cameras need to be mounted on solid capping. The capping needs to be cut (to accommodate the camera), and new #14X4" wood screws need to be installed on this new section of capping. Doing this will avoid the mechanic from lifting a section of capping for an underground ball.
5. After WINS or Focus is installed, check the operation of the 10<sup>th</sup> frame (3<sup>rd</sup> ball) extra cycle.
6. Please check the operation of the foul lights interface
7. The Steltronic sign off sheet should be filled out by the installer with the owner prior to leaving.