



**If you cut this white wire on the transformer, you are essentially cutting off the low voltage to the foul light.**

**If you connect this cut wire through a two conductor wire to the API connector #13, (labeled JP10 of the LOW connector on the API PCB) then WINS at the front desk can control the foul lights.**

