



The settings you will see below are supplied as a basic sample of where to start with settings for your pinsetters and how they will operate with Steltronic Focus Software.

The examples below are a starting point, and some fine tuning may be required.

On the last page of this document, you will find some descriptions of the settings. The descriptions are more detailed than what can be displayed on the screens.

If you have any questions, please contact [Steltronic Technical support](#)

Qubica TMS and Qubica Edge Pinsetters

The screenshot displays the Steltronic Focus-NEX - Front Desk 19.0.5.4 interface. The top menu bar includes 'Console', 'View', 'Go', 'Tools', 'Windows', and 'Help'. The main window is titled 'Lanes Manager' and contains a 'Pinsetter Settings [8 items]' section. This section features a row of eight numbered gear icons representing individual lanes. Below this, the interface is divided into four tabs: 'Basic', 'Advanced 1', 'Advanced 2', and 'Live view'. The 'Basic' tab is active and contains the following settings:

- Pinsetter control:** Radio buttons for On, Practice, Off, Auto (selected), and Extern.
- Practice mode settings:** Radio buttons for Throws and Time (selected). A 'Quantity (Thr / Min)' field is set to 10. Checkboxes for 'Pinsetter to Auto at the End of Practice' and 'Set Pinsetter at the End of Practice' are present.
- Firmware:** Checkboxes for 'Pinsetter phased with score', 'During Practice: Full set of pins for every ball', and 'Pinsetter on when practice'. Two green buttons are labeled 'Disable cycle with no active players' and 'Automatic foul line'.
- Note:** A section with five checkboxes and their corresponding descriptions regarding lane settings.

At the bottom of the 'Basic' tab, there are several control buttons: 'Set Pins and First Ball', 'Set Pins and Second Ball', 'Fights', 'Cycle or Riset Pinsetter', and 'Set Pinsetter'. The bottom right corner of the interface features three buttons: 'Send to lane', 'Send to lane and close', and 'Open Cash Drawer'. The task bar at the very bottom shows 'Task bar', 'Full screen', an 'Emergency shutdown' warning icon, the date and time 'Monday, January 31, 2022 3:08:14 PM', and the 'Open Cash Drawer' button.

Lanes Manager

Pinsetter Settings [8 items]

Lanes Manager

Leagues

Score Print Manager

Time Games

POS

Restaurant / Tabs

Cash Register

Reservations

Waiting List

Membership

Lockers

Time Clock Manager

BowlStatManagerF...

Payments Manager

Configuration Man...

Report System

Advertising manager

Products and Rates

Bowler Console Em...

Task bar

Pinsetter Settings [8 items]



Basic

Advanced 1

Advanced 2

Live view

Hardware connection

- Off
- Ball Change
- A.P.S. on 1st Ball
- A.P.S. on 1st / 2nd Ball
- Gutter plus Strike
- Gutter plus Strike also for Foul

Pinsetter Type

QAMF TMS NO_API

Special cycles

- Automatic Foul Line Management
- Change ball if gutter or 7-10
- No tap and 10th frame respot
- Modified cycle for strike

- 1st Ball Extra Cycle Delay (sec.) 2.5
- 2nd to 1st Ball Change Delay (sec.) 1.0
- 1st Ball Cycle after photo 2.0
- 2nd Ball Cycle after photo 2.0
- Extra cycle delay when foul and strike (sec.) 2.0
- Open Lane In Phase (sec.) 5
- Power Off Delay (sec.) 15
- Ball return power off delay (sec.) 20

Note

- Setting enabled for the items selected
- Setting disabled for the items selected
- The selected items do not have the same setting
- This background is for items who apply to the whole pair
- This background is for items who apply to the single lane

Lanes Manager

Pinsetter Settings [8 items]

- Lanes Manager
- Leagues
- Score Print Manager
- Time Games
- POS
- Restaurant / Tabs
- Cash Register
- Reservations
- Waiting List
- Membership
- Lockers
- Time Clock Manager
- BowlStatManagerf...
- Payments Manager
- Configuration Man...
- Report System
- Advertising manager
- Products and Rates
- Bowler Console Em...

Pinsetter Settings [8 items]

Basic	Advanced 1	Advanced 2	Live view
<p>2nd Ball lamp after clip ball max delay (sec.) <input type="text" value="5.0"/></p> <p>Timed MGR cmd (sec.) <input type="text" value="5.0"/></p> <p>Extra features</p> <p><input type="checkbox"/> Full Set to close Frame</p> <p><input type="checkbox"/> Full Set with Spare or Strike</p> <p><input type="checkbox"/> Reset after Ready</p> <p><input type="checkbox"/> Convertible 5 and 10 Pin</p> <p><input type="checkbox"/> Shield Installed</p>	<p><input checked="" type="checkbox"/> Set Pinsetter Enabled</p> <p><input type="checkbox"/> XLI Foul in Warning mode</p> <p><input checked="" type="checkbox"/> Override Practice settings when playing Tournament</p> <p>Figures</p> <p><input checked="" type="radio"/> No Figures</p> <p><input type="radio"/> GS-X Figures</p> <p><input type="radio"/> GS Figures</p> <p><input checked="" type="checkbox"/> GS-X and TMS Set Pins Enabled</p>		
<p>Note</p> <p><input checked="" type="checkbox"/> Setting enabled for the items selected</p> <p><input type="checkbox"/> Setting disabled for the items selected</p> <p><input type="checkbox"/> The selected items do not have the same setting</p> <p><input checked="" type="checkbox"/> This background is for items who apply to the whole pin</p> <p><input type="checkbox"/> This background is for items who Apply to the single lane</p>			

32	
Name	QAMF TMS NO_API
Par_0	0
Par_1	0
Par_2	0
Par_3	0
Par_4	0
Par_5	0
Par_6	0
Par_7	0
Par_8	0
Par_9	0
Par_10	0
Par_11	0
Par_12	0
Par_13	0
Par_14	0
Par_15	0
Par_16	0
Par_17	0
Par_18	0
Par_19	0
Par_20	0
Par_21	0
Par_22	0
Par_23	0
Par_24	0
Par_25	0
Par_26	0
Par_27	10
Par_28	30
Par_29	10
Par_30	10
Par_31	0
Par_32	0
Par_33	0
Par_34	0
Par_35	0

Par_36	0
Par_37	0
Par_38	0
Par_39	0
Par_40	0
Par_41	0
Par_42	0
Par_43	0
Par_44	0
Par_45	0
Par_46	0
Par_47	0
Par_48	0
Par_49	0
Par_50	0
Par_51	0
Par_52	0
Par_53	0
Par_54	0
Par_55	0
Par_56	0
Par_57	0
Par_58	0
Par_59	0
Par_60	0
Par_61	0
Par_62	0
Par_63	0
Par_64	0
Par_65	0
Par_66	0
Par_67	0
Par_68	0
Par_69	0
Par_70	0
Par_71	0
Par_72	0
Par_73	0

Par_73	0
Par_74	0
Par_75	0
Par_76	0
Par_77	0
Par_78	0
Par_79	0
Par_80	0
Par_81	0
Par_82	0
Par_83	0
Par_84	0
Par_85	0
Par_86	0
Par_87	0
Par_88	0
Par_89	0
Par_90	0
Par_91	0
Par_92	0
Par_93	0
Par_94	0
Par_95	0
Par_96	0
Par_97	0
Par_98	0
Par_99	0
Par_100	0
Par_101	0
Par_102	0
Par_103	0
Par_104	0
Par_105	0
Par_106	0
Par_107	0
Par_108	0
Par_109	0
Par_110	0

Par_111	0
Par_112	0
Par_113	0
Par_114	0
Par_115	0
Par_116	0
Par_117	0
Par_118	0
Par_119	0
Par_120	0
Par_121	0
Par_122	0
Par_123	0
Par_124	0
Par_125	0
Par_126	0
Par_127	0

Basic tab options

- Pinsetter Control: I think that it is already clear...
- Pinsetter Phased with score: if selected, when pinsetter and score are not on the same ball, the pins are not scored and no special cycles are executed (only normal cycle is executed)
- Ten pins in practice mode: if selected, when the Pinsetter control is set to Practice, a new set of pins is given with every throw.
- Pinsetter on when practice: if selected, when the Pinsetter control is set to Practice and the pinsetter is an AMF, instead of Practice, the pinsetter will be set in normal 10pin bowling
- Disable cycle with no active players: if selected, the API will not cycle the pinsetter if no player is active on lane
- Gutter / 7-10: if selected and the pinsetter has the capability to switch on second ball without cycling, this will happen if gutter or only pin 7 or only pin 10 or only pin 7 and 10 are knocked down
- Automatic foul line: if selected, the API will power ON and OFF the Foul lights as needed
- Respot enabled: actually not used

Advanced tab options

- **Hardware connection:**
 - "Off" -> no special interfacing available, only cycle
 - "Ball Change" -> pinsetter change ball capability - not yet implemented
 - "APS on 1st Ball" -> AMF APS on first ball only capability
 - "APS on 1st / 2nd Ball" -> AMF APS capability (1st and 2nd ball)
 - "Gutter plus Strike" -> for dumb pinsetter that needs to be informed if strike or gutter
 - "Gutter plus Strike also for Foul" -> VIA Bowling MC2 pinsetter
- **Tenth frame respot**
 - "None" -> no special cycles (No Tap, Foul, 10th frame, 10 pins in practice mode, etc.) performed
 - "Modified cycle" -> special capability (change ball, APS, strike, etc.) are used to perform special cycles (No Tap, Foul, 10th frame, 10 pins in practice mode, etc.) - not yet implemented
 - "Extra cycle" -> only the cycle is used to perform special cycles (No Tap, Foul, 10th frame, 10 pins in practice mode, etc.)

- Wait for 2nd Ball signal before Respot Delay: if selected and if "Extra cycle" respot is selected, the Respot Delay starts after pinsetter second ball lamp is activated and 1st ball Extra Cycle Delay starts after the end of Respot Delay, if not selected, the Respot Delay starts after the pins reading and 1st ball Extra Cycle Delay starts after the end of Respot Delay
- 1st Ball Cycle after photo: if selected, on first ball, the pinsetter is cycled after pins are read, if unselected, the pinsetter is cycled before pins are read
- 2st Ball Cycle after photo: if selected, on second ball, the pinsetter is cycled after pins are read, if unselected, the pinsetter is cycled before pins are read
- Automatic Foul Line Management: if selected, on pinsetters without foul cycle, the foul cycle is emulated with modified cycle or extra cycle respot - not yet implemented
- Figures Enabled: Brunswick GS series capability - not yet implemented
- Respot Delay: delay before respot on second ball (see also Wait for 2nd Ball signal before Respot Delay)
- 1st Ball Extra Cycle Delay: delay before respot on first ball - not yet implemented
- 2nd to 1st ball Change Delay: if Hardware connection is Ball Change and Automatic Foul Line Management is selected, this is the delay before issuing a Change Ball for completing after pinsetter second ball lamp is activated during the emulated Foul cycle - not yet implemented
- Open Lane in Phase: if > 0 , when a lane is opened with names, after this delay, if the second ball lamp is active, a cycle is given.
- Power Off Delay: if Pinsetter control is Auto, this is the delay before powering OFF the pinsetter when the game is finished
- Ball Return Power Off Delay: if Pinsetter control is Auto, this is the delay before powering OFF the Ball Return motor after the pinsetter is powered OFF

To Speed Up more the cycles, you can trim the photo delay.

You must enter in Configuration->Pinsetter->Brunswick A1/A2 Standard and then modify the parameter 24 for left lane delay and 25 for right lane delay.

The default value is 150, it means 3s because the step is 20ms; you can try lower values.

After changing the values, you click on save and reboot the VLC to have these parameters reloaded.

I hope that all of this information are clear enough...