

Steltronic Stelpad Pedestal Installation



Components necessary for Stelpad Pedestal assembly

A. Pedestal (Silver or Black)



B. Front Branding Plate



C. Plexiglass (available in Blue, Yellow, and Red)



D. Pedestal Back Plate



E. Touchscreen Monitor Top Plate



F. Wood screws or concrete anchors (4 per pedestal)



G. Pedestal base caps (4 per pedestal)



H. ELO Touchscreen



I. StelTab Computer



- J. Touchscreen and Computer Power Supply cords (1 of each per Stelpad)
- K. HDMI and USB Cables (1 of each per Stelpad)
- L. Power strip/surge protector (1 for each pair of lanes recommended; sold separately)

Assembly and Installation Instructions for the StelPad Pedestal

Step 1: Place the plexiglass and front branding plate on the front of each pedestal.

Step 2: Establish the location in the bowler's area where you wish to install the pedestal(s).

- Drill pilot holes for the wood floor screws.
- Drill access hole in flooring for cords and cabling to feed into the bottom of the pedestal base. Example below.



Step 3: With the pedestal laying on the floor, feed all necessary cables through the pedestal to their desired location.

- The network cable and power supply cord for the StelTab computer will feed to the bottom of the pedestal.
- The HDMI cable, USB cable and power supply cord for the touchscreen will feed from the base of the pedestal, through one of the side tubes to the touchscreen's resting mount.

Step 4: Secure the ends of all cables/cords in their locations at the top of the pedestal, then stand up the pedestal, placing it at its desired spot.

Step 5: Secure the base of the pedestal with the wood screws.

Step 6: Insert pedestal base caps once the screws are secured to cover the holes.

Step 7: Place the touchscreen in the mount and plug in the three cables/cords to their appropriate locations. NOTE: Your network cable will plug into the Stelpad computer. Plug the other items as shown.



Step 8: Secure the touchscreen into the pedestal with the monitor top plate and black screws provided.

Step 9: Plug in all cables/cords to their appropriate spots in the Stelpad computer.



Step 10: Power on the Stelpad computer and touchscreen.

Step 11: Place and secure the back pedestal plate in position.



You are ready to establish communications between the StelPad computer and your Focus server.