



The settings you will see below are supplied as a basic sample of where to start with settings for your pinsetters and how they will operate with Steltronic WINS Software.

The examples below are a starting point, and some fine tuning may be required.

If you have any questions, please contact [Steltronic Technical support](#)

# AMF 82-90 Next Generation Chassis

Lanes #9-#10

LEFT LANE	EPROM	RIGHT LANE
Dist. for speed: <input type="text" value="23"/> cm	<input type="button" value="FH"/>	Dist. for speed: <input type="text" value="23"/> cm
Pin read delay: <input type="text" value="3.0"/> sec	<input type="button" value="Set Defaults"/>	Pin read delay: <input type="text" value="3.0"/> sec
<input type="button" value="Adv. Parameters"/>		

**COMMON**

Pinsetter:  ▼

**Hardware connection**

- None:
- 1st->2nd ball signal:
- APS:
- Strike/Gutter out:
- APS in 1st. and 2nd ball:

**No Tap + 10th frame respot**

- None:
- Modified cycle:
- Extra cycle:
- 2nd ball extra cycle delay:

1 Camera per lane:

Start distance:  cm

Off delay:  sec

Ball return power off delay:  sec

Automatic Foul Line:

Cycle after pin read (1st ball):

Cycle after pin read (2nd ball):

Advanced IRETRO settings Lanes #9-#10

Parameter 02h	16
Parameter 03h	16
Parameter 04h	16
Parameter 05h	4
Parameter 06h	4
Parameter 07h	4
Parameter 0Fh	10
Parameter 15h	0
Parameter 16h	50
Parameter 1Bh	0
Parameter 1Ch	12
Parameter 1Dh	10
Parameter 1Eh	0
Parameter 1Fh	16

Signal polarity (P1A)

Trigger

-  +

2nd ball

-  +

Foul

-  +

Pins

-  +

Cancel

OK